Thanks for buying one of my loft bed kits. If you have any questions during the process, please don't hesitate to contact me and I'll help you. Also, the boxes have left the shop in good condition. If there is any apparent trauma to the boxes or contents within, please contact me immediately. 615-483-3256

-Kelly Zullo: Chicago Loft Bed

Locate the boards labeled "mattress platform"
There will be a center, 2 sides and ends.
Lay them out as pictured.

Screw in the corners where the holes are with the long screws. They will be in a bag labeled "Long screws". Do not leave any gaps between boards. If a board happened to warp in shipping, please notify me so I can help or replace it for you.

To affix the center platform support, use the 4 long silver screws, located in the "long screws" bag.

After you've finished creating the mattress platform box, screw in the mattress slats using the small screws.
Use a slat as a spacer.

** On the 2 end slats, skip the innermost screw like in the above picture. There is a bolt that will go there in the following steps.